

TE PARI Loadbar plug wiring

Load cell plug should be wired up

- EXC, Black pin 1
- + EXC, Red pin 2
- SIGNAL White pin 3
- + SIGNAL Green pin 4

Insert a 3k3 resistor between pin 5 and pin 7 in both plugs. This makes our loadbars compatible with other manufacturers indicators.

