## FX41 set up for Racewell.

Turn indicator ON Press set up (use enter button to confirm setting then move on) Prefixing =OFF Weight Gain = OFF Percent = 51 Draft = EID on line Auto draft = Racewell (or 'on' in older models) EID = OFF Trigger = External Band Rate = 19200 Dupl. ID Check = OFF Multiple Weigh = OFF Display Release = ON Zero Track = ON Units = KG Work through until SAVED shows on screen. Then, use WEIGH MODE key to scroll through until HI-SPEED shows on screen. **Draft Limits** 1 = 20kg - Enter 2 = 40 kg - Enter

Auto release on.